



Dyson Cinetic Animal Canister Unlocking Mechanism Spring Replacement

This guide will instruct you on how to replace the main spring component of the canister unlocking mechanism.

Written By: Allison Turnbaugh



INTRODUCTION

Unable to quickly remove your canister from the vacuum body? This guide will show you how to replace the spring inside the opening mechanism.



TOOLS:

- [Tweezers](#) (1)



PARTS:

- [Dyson DC47 Cinetic Animal Opening Spring](#) (1)

Step 1 — Canister Unlocking Mechanism Spring



- If the top handle does not pop up when trying to remove canister, press the gray button as you gently pull up on the top handle.

Step 2



- Locate the spring in the small opening between the handle and ball of the vacuum body.

Step 3



- Pull out the spring by carefully inserting tweezers into the opening.
- Carefully remove the spring.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-21 01:55:22 PM.